

Note

The AeroElectric Connection is a living document and is constantly being updated. You purchase the book only one time. You may keep your book current by downloading updates from

<http://aeroelectric.com/whatsnew.html>

Table of Contents

Chapter	Topic
1	D.C. Fundamentals
2	Batteries
3	Engine Driven Power Sources
4	Voltage Regulators
5	Grounding
6	Over Voltage Protection
7	Electrical System Instrumentation
8	Wire Selection and Installation
9	Wire Termination and Connectors
10	Circuit Protection
11	Switches, Relays and Contactors
12	Lighting and Lighting Controls
13	Antennas and Feedlines
14	Temperature Measurement
15	(reserved) Pressure Measurement
16	Electromagnetic Compatibility (Noise)
17	Electrical System Reliability
18	Audio Systems
Appendix Z	Power Distribution Diagrams

Copyright Notice

All work product under in the *AeroElectric_Connection* folder is Copyrighted 1988 through 2009 inclusively. None of this material may be copied or transmitted electronically or on hard copy to persons other than the original purchaser without written permission of the publisher who is:

Robert L. Nuckolls III, AeroElectric Connection, P.O. Box 130, Medicine Lodge, KS 67104-0130,
Email: bob.nuckolls@aeroelectric.com

Original purchasers of this work may make back-up copies of the CD. Original purchasers may transfer any of these files to personally owned computers and/or print hard copies for personal use only.

All other materials on this CD may be copied and freely transmitted or distributed in any form as long as no modifications are made and authorship of the work product is fairly cited.

This page intentionally left blank