


Transponder

**COLLINS  
TDR-950/ 950L**

Connector



Circuit	Pin #	Notes
14 VOLTS DC IN.....	14	
14V DIMMER.....	13	Note 1
A1.....	12	
A2.....	10	
A4.....	7	
B1.....	6	
B2.....	5	
B4.....	4	
C1.....	8	
C2.....	11	
C4.....	9	
D4.....	3	
EXT SUPPR.....	2	
GROUND.....	1	
REMOTE I/ D.....	15	

**Notes**

1. For 28 volts use 56 ohm 15 watt resistor in series.

For familiarization only. Consult the manufacturers current data.