



NOTES:
 A - Do not ground the coax cable shield between the Panel Unit and the Remote Unit. The shield is grounded only at the Remote Unit end and any additional ground points will form ground loops which may cause false reply indications. The coax cable length is not critical, however, installations requiring a cable longer than 192", RG 58A/u should be used to minimize power loss.
 B - If cable is too long, shorten at P701 end. Terminate ground (Black #22) to cable shield as shown.

AT5-A, AT6-A ELECTRICAL CONNECTOR INSTALLATION WIRING FOR 14/28V UNIVERSAL CABLE